

Yealink Wifi Set-up

If you've ordered a WiFi-enabled Yealink phone from us, this quick-start guide will walk you through setting up the WiFi connection.

Initial Setup (First-Time Use)

When you plug in the phone for the first time, you'll be prompted to change the default password.

- Proceed with changing it — this is required.
 - The password will later be updated automatically as part of our setup process.
 - For simplicity, we recommend temporarily changing it to: **3333446441**
 - The default password is: **admin**
-

Connecting to WiFi

1. On the phone, go to:
Menu → Settings → Basic Settings
 2. Select **WiFi**, and make sure it is turned **ON**.
 3. Scroll down to **Available Networks**, then press **Scan**.
 4. After the scan completes, press **Enter**.
 5. Find your WiFi network and press **Connect**.
 6. When prompted, enter your WiFi password.
 - Tip: Enable "**Show Password**" to see what you're typing.
-

Revision #2

Created 3 July 2025 13:01:08 by Oliver

Updated 3 July 2025 14:46:41 by Oliver