

Pairing an additional Yealink Handset to the W70B

1. Put the W70B base into registration mode

- Press and **hold the paging / wireless button** (the circular button with the Wi-Fi/phone icon) on the W70B for ~5 seconds until its registration LED (the phone icon) starts flashing. This means the base is in registration mode. It will time out automatically after about 90 seconds if no handset registers.

<https://help.nextiva.com/servlet/rtalImage?eid=ka08Y000000IRIB&feoid=00N4x00000Qr0kx&refid=>

2. On the W73H handset — start registration

Press **OK** → **Settings** → **Registration** → **Register Handset** and select base 1 if prompted from the list.

https://help.sprucehealth.com/hc/article_attachments/27447242905755

3. Complete the pairing

- After selecting the base, the handset will search and attempt to register.
- When prompted, enter the registration PIN. The default PIN is usually **0000**.
- Upon success, the handset will display **“Handset Subscribed”** (showing the base’s identifier) and initialize. Then it will show its internal handset number/name.

If you have multiple handsets sharing one account, you may need to configure the number assignment in the online GUI. Please contact support@globe2.net should you need further assistance.

Revision #1

Created 1 August 2025 13:33:52 by Oliver

Updated 1 August 2025 13:37:31 by Oliver